

KCP4000 (13.56MHz MIFARE) Proximity Key

Q N° 102



FRONT



BACK

KCP4000 Proximity Keyfob



SIDE



Each KCP4000 proximity keyfob is engraved with its unique 10 digit ID number.

Dimensions code: 52mmL x 34mmW x 5mmD

RESIDENTS

Use your proximity key to enter through those doors authorised to you. Simply hold the proximity key in front of the proximity reader in the door panel. The LED will illuminate green to indicate that the proximity key is OK and the door will unlock.

Please keep a record of the unique 10 digit number engraved on each proximity key issued to you.

KCP4000 proximity keys are always part of a unique group of keys which we refer to as a "Site Code". Example: Each block of flats has its own site code to facilitate administration – this means you know which block a proximity key belongs to simply by looking at its first 5no digits.

So, each proximity key in a particular group starts with the same first 5no digits (the site code) followed by the user identification number 00001, 00002, 00003 and so on. This enables individual and batch programming and deletion. Most importantly, it means there is an exact record of proximity key numbers provided, for example: 0197000001 – 0197000150. Subsequent orders will continue the sequence 0197000151 etc.

Concierge/Management company: Please order spares on a block by block basis.