

Nothing is as easy to use as TVTEL®

A

Visitor enters your flat number (for example 12 for flat 12) or finds your flat on the display and presses the bell button to call you.



B

You just answer on your normal landline, mobile or cordless phone. You don't even have to be at home! It is no different than being called by a friend.



C

If you want to let your visitor in, just press the 0 button on your phone. If not, simply end the call.



D

If you want to see the picture from the camera in the TVTEL door panel, it is always on Digital Freeview! You don't even need to be called to see it.



Usually channels 801, 802 or 803.