

How to use your IP-VIP™ card



The IP-VIP™ card will not activate UNTIL presented to the BATICONNECT® proximity reader.

Place your enrolled finger

(typically your thumb) on the sensor and ensure that the whole sensor, including the gold bezel, is covered by your finger.


- Hold the card lightly to avoid squashing your fingerprint features against the sensor.
- Ensure your finger is dry.

Now present the IP-VIP™ proximity card to the BATICONNECT® IPGUARD® / IPVIEW® proximity reader panel, or the secondary door proximity reader.



If you find that the card is taking very long (>5 seconds) to power up then place the card in the landscape/horizontal position against the proximity reader.

IP-VIP card presented to proximity reader:

with **correct finger** = Flashing green light 

with **incorrect finger** = Solid red light 

with **no finger** = Nothing will happen 