



**Code: D**

Visitor Call Panel on vehicle gate



**Code: D1**

Prox reader on vehicle gate



**LEGEND**


	Visitor Call Point (VCP): Hardwired IP Video panel, or IPGUARD 4G/IP/GSM Smart panel.	L48
	Proximity reader.	L10
	Gate automation control equipment.	L11
	PROTECTED door release exit button.	L47
	Radio receiver.	L15
	Keypad for coded access.	L32
	Emergency breakglass with alarmed cover.	L50
	NACD control unit and power supply.	L17
	Proximity keyfob reader and keypad for coded access.	L31

- A** Class E (CAT6) U/UTP x 4no + Earth 1.5mm<sup>2</sup> (6491X)
- B** 3-core 1.5mm<sup>2</sup> flex cable (3183Y)
- C** Class E (CAT6) U/UTP + Earth 1.5mm<sup>2</sup> (6491X)
- D** Class E (CAT6) U/UTP
- E** Lock circuit cable ref. 4 x 1 YY/LSZH per lock (4-core, 1mm<sup>2</sup>/core)
- F** Class E (CAT6) U/UTP x 2no
- G** Lock circuit cable ref. 4 x 1 YY/LSZH per lock (4-core, 1mm<sup>2</sup>/core) + Class E (CAT6) U/UTP x 1no
- V** FP200 (BS5839-1 / Class 1 CU compliant) 1mm<sup>2</sup>/core cable, 3-core + 1-core Earth. (Red sheaf, brown, grey, black + green/yellow cores)

**IMPORTANT** Please make sure you also have a copy of the NACD Full Legend document.


**Code: D2**

Keypad on vehicle gate












**Code: D3**

Prox + keypad on vehicle gate



**LEGEND**


	Visitor Call Point (VCP): Hardwired IP Video panel, or IPGUARD 4G/IP/GSM Smart panel.	L48
	Proximity reader.	L10
	Gate automation control equipment.	L11
	PROTECTED door release exit button.	L47
	Radio receiver.	L15
	Keypad for coded access.	L32
	Emergency breakglass with alarmed cover.	L50
	NACD control unit and power supply.	L17
	Proximity keyfob reader and keypad for coded access.	L31

- A** Class E (CAT6) U/UTP x 4no + Earth 1.5mm<sup>2</sup> (6491X)
- B** 3-core 1.5mm<sup>2</sup> flex cable (3183Y)
- C** Class E (CAT6) U/UTP + Earth 1.5mm<sup>2</sup> (6491X)
- D** Class E (CAT6) U/UTP
- E** Lock circuit cable ref. 4 x 1 YY/LSZH per lock (4-core, 1mm<sup>2</sup>/core)
- F** Class E (CAT6) U/UTP x 2no
- G** Lock circuit cable ref. 4 x 1 YY/LSZH per lock (4-core, 1mm<sup>2</sup>/core) + Class E (CAT6) U/UTP x 1no
- V** FP200 (BS5839-1 / Class 1 CU compliant) 1mm<sup>2</sup>/core cable, 3-core + 1-core Earth. (Red sheaf, brown, grey, black + green/yellow cores)

**IMPORTANT** Please make sure you also have a copy of the NACD Full Legend document.


**Code: D4**

Prox reader on either side of vehicle gate












**Code: D5**

Prox reader on either side of vehicle gate  
+ alarmed breakglass



**LEGEND**

-  Visitor Call Point (VCP): Hardwired IP Video panel, or IPGUARD 4G/IP/GSM Smart panel. L48
-  Proximity reader. L10
-  Gate automation control equipment. L11
-  PROTECTED door release exit button. L47
-  Radio receiver. L15
-  Keypad for coded access. L32
-  Emergency breakglass with alarmed cover. L50
-  NACD control unit and power supply. L17
-  Proximity keyfob reader and keypad for coded access. L31

- A** Class E (CAT6) U/UTP x 4no + Earth 1.5mm<sup>2</sup> (6491X)
- B** 3-core 1.5mm<sup>2</sup> flex cable (3183Y)
- C** Class E (CAT6) U/UTP + Earth 1.5mm<sup>2</sup> (6491X)
- D** Class E (CAT6) U/UTP
- E** Lock circuit cable ref. 4 x 1 YY/LSZH per lock (4-core, 1mm<sup>2</sup>/core)
- F** Class E (CAT6) U/UTP x 2no
- G** Lock circuit cable ref. 4 x 1 YY/LSZH per lock (4-core, 1mm<sup>2</sup>/core) + Class E (CAT6) U/UTP x 1no
- V** FP200 (BS5839-1 / Class 1 CU compliant) 1mm<sup>2</sup>/core cable, 3-core + 1-core Earth. (Red sheaf, brown, grey, black + green/yellow cores)

**IMPORTANT** Please make sure you also have a copy of the NACD Full Legend document.